

## § 95.407

of Defense you may be required to comply with additional regulations imposed by the commanding officer of the installation.

(b) If your C/B station will be constructed on an environmentally sensitive site, or will be operated in such a manner as to raise environmental problems, under §1.1307 of this chapter, you must provide an environmental assessment, as set forth in §1.1311 of this chapter, and undergo the environmental review, §1.1312 of this chapter, before commencement of construction.

[48 FR 24894, June 3, 1983, as amended at 55 FR 20398, May 16, 1990]

### HOW TO OPERATE A CB STATION

## § 95.407 (CB Rule 7) On what channels may I operate?

(a) Your CB station may transmit only on the following channels (frequencies):

Channel	Frequency (megahertz— MHz)
1 .....	26.965
2 .....	26.975
3 .....	26.985
4 .....	27.005
5 .....	27.015
6 .....	27.025
7 .....	27.035
8 .....	27.055
9 .....	27.065
10 .....	27.075
11 .....	27.085
12 .....	27.105
13 .....	27.115
14 .....	27.125
15 .....	27.135
16 .....	27.155
17 .....	27.165
18 .....	27.175
19 .....	27.185
20 .....	27.205
21 .....	27.215
22 .....	27.225
23 .....	27.255
24 .....	27.235
25 .....	27.245
26 .....	27.265
27 .....	27.275
28 .....	27.285
29 .....	27.295
30 .....	27.305
31 .....	27.315
32 .....	27.325
33 .....	27.335
34 .....	27.345
35 .....	27.355
36 .....	27.365
37 .....	27.375
38 .....	27.385
39 .....	27.395
40 .....	27.405

<sup>1</sup> See paragraph (b) of this section.

## 47 CFR Ch. I (10–1–02 Edition)

(b) Channel 9 may be used only for emergency communications or for traveler assistance.

(c) You must, at all times and on all channels, give priority to emergency communication messages concerning the immediate safety of life or the immediate protection of property.

(d) You may use any channel for emergency communications or for traveler assistance.

(e) You must share each channel with other users.

(f) The FCC will not assign any channel for the private or exclusive use of any particular CB station or group of stations.

(g) The FCC will not assign any channel for the private or exclusive use of CB stations transmitting single sideband or AM.

## § 95.408 (CB Rule 8) How high may I put my antenna?

(a) *Antenna* means the radiating system (for transmitting, receiving or both) and the structure holding it up (tower, pole or mast). It also means everything else attached to the radiating system and the structure.

(b) If your antenna is mounted on a hand-held portable unit, none of the following limitations apply.

(c) If your antenna is installed at a fixed location, it (whether receiving, transmitting or both) must comply with either one of the following:

(1) The highest point must not be more than 6.10 meters (20 feet) higher than the highest point of the building or tree on which it is mounted; or

(2) The highest point must not be more than 18.3 meters (60 feet) above the ground.

(d) If your CB station is located near an airport, and if you antenna structure is more than 6.1 meters (20 feet) high, you may have to obey additional restrictions. The highest point of your antenna must not exceed one meter above the airport elevation for every hundred meters of distance from the nearest point of the nearest airport runway. Differences in ground elevation between your antenna and the airport runway may complicate this formula. If your CB station is near an airport, you may contact the nearest